

Version 2 02-Aug-05

Connector	Intended for	Network profile	Notes	Default Trust Group	Unit acts as DHCP Client	Unit acts as DHCP server	Default Static Address given to this port
LAN1	LAN	Quick-Configuration LAN	Automatic initial configuration of the unit's LAN connector.	Trusted	Yes (if other DHCP server)	Yes (if no other present)	10.0.0.1
		Managed LAN	For networks with an existing DHCP server.	Trusted	Yes	No	N/A
		Private LAN	For networks with static addresses.	Trusted	No	Yes	10.0.0.1
LAN2	Second LAN, WAN or DMZ	Quick-Configuration WAN	Automatic initial configuration of the unit's WAN connector.	Internet	Yes	No	192.168.43.1
		Ethernet Cable/ADSL	Used for connecting to an external device that is a DHCP server.	Internet	Yes	No	N/A
		DMZ	Classic DMZ.	DMZ	No	Can be enabled	192.168.42.1
		Ethernet Router	Used when the connector requires a static address.	Internet	No	Can be enabled	192.168.43.1
		LAN with Public Terminals	The network allows restricted user access.	Controlled	No	Can be enabled	192.168.41.1
LAN3	Second LAN, WAN or DMZ	DMZ	Classic DMZ.	DMZ	No	Can be enabled	192.168.42.1
		Ethernet Cable/ADSL	Used for connecting to an external device that is a DHCP server.	Internet	Yes	No	N/A
		Ethernet Router	Used when the connector requires a static address.	Internet	No	Can be enabled	192.168.43.1
		LAN with Public Terminals	The network allows restricted user access.	Controlled	No	Can be enabled	192.168.41.1
		Managed LAN	For networks with an existing DHCP server.	Trusted	Yes	No	N/A
		Private LAN	For networks with static addresses.	Trusted	No	Yes	10.0.0.1
		Quick-Configuration LAN	Automatic initial Configuration of the unit's LAN connector.	Trusted	Yes (if other DHCP server)	Yes (if no other present)	10.0.0.1
		Quick-Configuration WAN	Automatic initial configuration of the unit's WAN connector.	Internet	Yes	No	192.168.43.1